
RFPW.E184741

Purging and Pressurizing Controls and Accessories for Use in Hazardous Locations

[Page Bottom](#)

[Print-friendly version](#)

[Questions?](#)

Purging and Pressurizing Controls and Accessories for Use in Hazardous Locations

[See General Information for Purging and Pressurizing Controls and Accessories for Use in
Hazardous Locations](#)

PEPPERL & FUCHS INC

E184741

1600 ENTERPRISE PKY

TWINSBURG, OH 44087 USA

Pressure relief vents, Models 335211, 335211-90, 335311, 335311-90 with prefix US.

Purge controls, Types Y, Z, for use in hazardous locations, Models 3200, 3201, 3202, 3203, 3300, 3301, 3302 followed by 00, followed by B, L, P, R, T or U, followed by YZ; all models with prefix US.

Types Y, Z, for use in hazardous locations with explosion-proof pressure switch for Class I, Groups C and D and Class II, Groups E, F and G hazardous locations; Models 4200, 4201, 4202, 4203, 4300, 4301, 4302 followed by 00, followed by B, L, R, T or U, followed by YZ; all models with prefix US.

Types Y, Z, for use in hazardous locations with explosion proof pressure switch for Class I, Division 1&2, Groups A, B, C, D ; Models 4200, 4201, 4202, 4203, 4300, 4301, 4302 followed by 00, followed by L, R, T, B or U, followed by YA or YZ, followed by B, F, N, S or V, followed by 120VAC or 220VAC, all models with prefix US.

Types X, for use in nonhazardous locations with intrinsically safe circuit extensions for Class I, Groups A, B, C, D, Class II, Groups E, F, G, and Class III hazardous locations when connected accordance with control drawing No. 116-0161; Models US-211120, -211120-220, -211121, -211121-220.

Type X for use in Class I, Groups B, C, D, Class II, Groups E, F, G and Class III Hazardous locations with intrinsically safe circuit extensions for Class I, Groups A, B, C, D, Class II, Groups E, F, G and Class III hazardous locations when connected in accordance with control drawing 116-0161; Models US-214120, -214120-220, -214121, -214121-220.

Vent Units for use in Class I, Groups A, B, C and D, Class II, Groups E, F and G and Class III hazardous locations when connected in accordance with control drawing 116-0161, Models US-2151 followed by -10, -19, -20, -29, -30, -39, -40, -49, -50, -59, -60, -69, -70, -79, -80 or -89, 215121 and 215122.

Purge controls , Models 11, 1001A, 1001B, 1001C, 1002, 1003, 1004, 1005, 1011, 1012, UC01A followed by -LPS, may be followed by C1 or C11, may be followed by -LH, -PM, -RH, BM, RM, TM, UM or WM.

Models 11, 1001A, 1001B, 1001C, 1002, 1003, 1004, 1005, UC01A followed by -WPSA, may be followed by C1 or C11, may be followed by -LH, -RH, BM, PM, TM, UM or WM.

Models 11, 1001A, 1001B, 1001C, 1002, 1003, 1004, 1005, UC01A followed by -WPS, may be followed by C1 or C11, may be followed by -LH, -RH, BM, PM, RM, TM, UM or WM.

Purge vents , Model EPV followed by -1, -2, -3, -3.5, -4 or -5, followed by -SA, may be followed by -90.

Model 2001 followed by A, B or C, followed by -STD, may be followed by C1 or C11, may be followed by -LH, -RH, -RM, -TM, -BM, -WM, -UM or -PM.

Models 2002, 2003, 2004, 2005 followed by -STD, -SA or -FA, may be followed by C1 or C11, may be followed by -LH, -RH, -RM, -TM, -BM, -WM, -UM or -PM.

Models 3003, 3004 followed by -LPS, may be followed by C1 or C11, may be followed by -CK, -HM, -LH, -RH, -BM, -PM, -RM, -TM, -UM, -VM or -WM.

Models 3003, 3004 followed by -WPSA, may be followed by C1 or C11, may be followed by -CK, -HM, -LH, -RH, -BM, -PM, -RM, -TM, -UM, -VM or -WM.

Models 3003, 3004 followed by -WPS, may be followed by C1 or C11, may be followed by -CK, -HM, -LH, -RH, -BM, -PM, -RM, -TM, -UM, -VM or -WM.

Purge controls provide optional intrinsically safe circuits for Class I, Groups B, C and D, and Class II, Groups E, F and G hazardous locations when connected in accordance with the manufacturer's operating manual. Manual numbers correspond to purge control model number.

Models 4003, 4004 followed by -FA, -SA, or -STD, followed by -CI, may be followed by -WPI or -LPI, may be followed by -VM, -HM, -CKH or -CKV.

Purge vent , Model EPV followed by -3 or -4, followed by -SA, followed by -00 or -90, followed by -SM.

[Last Updated](#) on 2004-02-19

[Page Top](#)

[Notice of Disclaimer](#)

[Questions?](#)

[UL Listed and Classified Products](#)

[UL Recognized Components](#)

[Products Certified for Canada](#)

This page and all contents are Copyright © 2005 by Underwriters Laboratories Inc.®

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from Underwriters Laboratories Inc." must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "Copyright © 2005 Underwriters Laboratories Inc.®"